

# IESTI01 - TinyML

Gesture Classification  
Edge Impulse Studio Project

Prof. Marcelo Rovai

June 16<sup>th</sup>, 2021



# Feature Extraction & Gesture Classification

## Project Time!

ei-motion-project-nn-classifier.ipynb



The screenshot shows the Edge Impulse homepage. At the top right, there are two buttons: "Login" and "Sign Up". A red dashed circle highlights the "Sign Up" button. The rest of the page includes the Edge Impulse logo, navigation links for Solutions, Docs, Forum, and Blog, and a search bar.



Solutions Docs Forum Blog

Login

Sign Up

# Making things smarter

Edge Impulse is the leading development platform for machine learning on edge devices, free for developers and trusted by enterprises.

Name

Email


Sign up for free



ELEPHANT  
Human Proximity Confirmed

Trusted by thousands of embedded developers running critical machine learning projects across millions of data samples.





- MJRoBot (Marcelo Rovai) / Sound-Classification-Blender-Faucet
- MJRoBot (Marcelo Rovai) / oi\_rovis\_kws
- MJRoBot (Marcelo Rovai) / Eggs AI
- MJRoBot (Marcelo Rovai) / Accelerometer-Nano-Ble-IoT
- MJRoBot (Marcelo Rovai) / video\_tinyml\_raw

Dashboard - IESTI01 - Gesture Classification - Edge Impulse

# MJRoBot (Marcelo Rovai) / IESTI01 - Gesture Classification

This is your Edge Impulse project. From here you can collect data, train your machine learning model, and deploy it to your device.

Welcome to your new Edge Impulse project!

You're ready to add real intelligence to your edge devices. Let's set up your project. What type of data are you dealing with?

**Creating your first impulse (0%)**

**Acquire data**  
Every Machine Learning project starts with data. You can collect data from your device, a development board or your cloud storage.

**LET'S COLLECT SOME DATA**

**Design an impulse**  
Teach the model to interpret the data. Use this to categorize new sensor readings.

**GETTING STARTED: CONTINUOUS**

**GETTING STARTED: RESPONDING**

**GETTING STARTED: ADDING**

**Deploy**  
Package the complete impulse up, from signal processing code to trained model, and deploy it on your device. This ensures that the impulse runs with low latency and without requiring a network connection.

**DEPLOY YOUR MODEL**

**Accelerometer data**  
Analyze movement of your device in real-time to predict machine failure, detect human gestures, or monitor rotating machines.

**Audio**  
Listen to what's happening around you to create voice interfaces, listen to keywords, detect audible events, or to hear what's happening around your device.

**Images**  
Add sight to your sensors with image classification or object detection - to detect humans and animals, monitor production lines or track objects.

**Something else**  
Different sensor? No problem! You can collect and import data from any sensor, from environmental sensors to radars - and deploy your trained model back to virtually any device.

I know what I'm doing, hide this wizard!

**Sharing**

Your project is private.

**Make this project public**

**Summary**

**DEVICES CONNECTED**  
0

**DATA COLLECTED**  
-

**Collaborators**

MJRoBot (Marcelo Rovai) OWNER

**Project info**

EDGE IMPULSE

- Dashboard
- Devices
- Data acquisition
- Impulse design
  - Create impulse
  - Retrain model
- Live classification
- Model testing
- Versioning
- Deployment

GETTING STARTED

- Documentation
- Forums

studio.edgeimpulse.com

Dashboard - IESTI01 - Gesture Classification - Edge Impulse

EDGE IMPULSE

Project info Keys Export

MJRoBot (Marcelo Rovai)

Dashboard Devices Data acquisition Impulse design Create impulse Retrain model Live classification Model testing Versioning Deployment

Creating your first impulse (0% complete)

Acquire data

Every Machine Learning project starts with data. You can capture data from a development board or your phone, or import data you already collected.

LET'S COLLECT SOME DATA

Design an impulse

Teach the model to interpret previously unseen data, based on historical data. Use this to categorize new data, or to find anomalies in sensor readings.

GETTING STARTED: CONTINUOUS MOTION RECOGNITION

GETTING STARTED: RESPONDING TO YOUR VOICE

GETTING STARTED: ADDING SIGHT TO YOUR SENSORS

Deploy

Package the complete impulse up, from signal processing code to trained model, and deploy it on your device. This ensures that the impulse runs with low latency and without requiring a network connection.

DEPLOY YOUR MODEL

Sharing

Your project is private.

Make this project public

Devices Connected: 0

Data Collected: -

Collaborators

MJRoBot (Marcelo Rovai) OWNER

Project info

studio.edgeimpulse.com

Dashboard - IESTI01 - Gesture Classification - Edge Impulse

EDGE IMPULSE

MJRoBot (Marcelo Rovai)

Project info Keys Export

# MJRoBot (Marcelo Rovai)

This is your Edge Impulse project. From here you can collect data, train your model, and deploy it to your own devices.

Creating your first impulse (0%)

Acquire data

Every Machine Learning project starts with data. You can collect data from a development board or your mobile phone.

LET'S COLLECT SOME DATA

Design an impulse

Teach the model to interpret movement, audio, or images. Use this to categorize new data. Readings.

GETTING STARTED: CONTINUOUS

GETTING STARTED: RESPONDING

GETTING STARTED: ADDING

Deploy

Package the complete impulse model, and deploy it on your own device. Run it at low latency and without requiring a network connection.

DEPLOY YOUR MODEL

## Collect data

You can collect data from development boards, from your own devices, or by uploading an existing dataset.

Connect a fully supported development board

Get started with real hardware from a wide range of silicon vendors - fully supported by Edge Impulse.

Browse dev boards

Use your mobile phone

Use your mobile phone to capture movement, audio or images, and even run your trained model locally. No app required.

Show QR code

Use your computer

Capture audio or images from your webcam or microphone, or from an external audio device.

Collect data

Data from any device with the data forwarder

Capture data from any device or development board over a serial connection, in 10 lines of code.

Show docs

Upload data

Already have data? You can upload your existing datasets directly in WAV, JPG, PNG, CBOR, CSV or JSON format.

Go to the uploader

Integrate with your cloud

The enterprise version of Edge Impulse integrates directly with the data stored in your cloud platform.

Contact us

Sharing

Your project is private.

Make this project public

Summary

DEVICES CONNECTED 0

DATA COLLECTED -

Collaborators

MJRoBot (Marcelo Rovai) OWNER

Project info

studio.edgeimpulse.com

Dashboard - IESTI01 - Gesture Classification - Edge Impulse

EDGE IMPULSE

Project info Keys Export

MJRoBot (Marcelo Rovai)

Dashboard Devices Data acquisition Impulse design Create impulse Retrain model Live classification Model testing Versioning Deployment

Creating your first impulse (0%)

Acquire data Every Machine Learning project needs training data. You can collect data from a development board or your smartphone. [LET'S COLLECT SOME DATA](#)

Design an impulse Teach the model to interpret sensor readings. Use this to categorize new sensor readings. [GETTING STARTED: CONTINUOUS](#) [GETTING STARTED: RESPONDING](#) [GETTING STARTED: ADDING](#)

Deploy Package the complete impulse up, from signal processing code to trained model, and deploy it on your device. This ensures that the impulse runs with low latency and without requiring a network connection. [DEPLOY YOUR MODEL](#)

Collect data

You can collect data from any smartphone. From your smartphone go to [this URL](#), or scan the QR code below.



Sharing

Your project is private. [Make this project public](#)

Summary

DEVICES CONNECTED 0

DATA COLLECTED -

Collaborators

MJRoBot (Marcelo Rovai) OWNER

Project info

This is your Edge Impulse project. From here you acquire new training data, design impulses and train models.

# MJRoBot (Marcelo Rovai) / IESTI01 - Gesture Classification

studio.edgeimpulse.com

Dashboard - IESTI01 - Gesture Classification - Edge Impulse

EDGE IMPULSE

Project info Keys Export

MJRoBot (Marcelo Rovai)

Dashboard Devices Data acquisition Impulse design Create impulse Retrain model Live classification Model testing Versioning Deployment

Creating your first impulse (0%)

Collect data

Acquire data

Every Machine Learning project starts with collecting data. You can collect data from a development board or your phone.

LET'S COLLECT SOME DATA

Design an impulse

Teach the model to interpret the data. Use this to categorize new sensor readings.

GETTING STARTED: CONTINUOUS MOTION RECOGNITION

GETTING STARTED: RESPONDING TO YOUR VOICE

GETTING STARTED: ADDING SIGHT TO YOUR SENSORS

Deploy

Package the complete impulse up, from signal processing code to trained model, and deploy it on your device. This ensures that the impulse runs with low latency and without requiring a network connection.

DEPLOY YOUR MODEL

Device phone\_kl72ebm0 is now connected

Get started!

Sharing

Your project is private.

Make this project public

Summary

DEVICES CONNECTED 0


DATA COLLECTED -

Collaborators

MJRoBot (Marcelo Rovai) OWNER

Project info

# Gesture Data Capture



studio.edgeimpulse.com

Data acquisition - IESTI01 - Gesture Classification - Edge Impulse

MJRoBot (Marcelo Rovai)

EDGE IMPULSE

DATA ACQUISITION (IESTI01 - GESTURE CLASSIFICATION)

Training data Test data

Did you know? You can capture data from any device or development board, or upload your existing datasets - Show options

DATA COLLECTED  
5m 24s

LABELS  
4

Collected data

SAMPLE NAME	LABEL	ADDED	LENGTH
up_down.285cifl0	up_down	Today, 17:06:12	10s
up_down.285chk0u	up_down	Today, 17:05:44	5s
up_down.285cgt13	up_down	Today, 17:05:20	10s
left_right.285cfanr	left_right	Today, 17:04:29	10s
left_right.285ceqea	left_right	Today, 17:04:12	10s
left_right.285ce9b5	left_right	Today, 17:03:54	10s
left_right.285cdp4k	left_right	Today, 17:03:38	10s
left_right.285cd7mh	left_right	Today, 17:03:20	10s
left_right.285ccksh	left_right	Today, 17:03:01	10s
left_right.285cbio4	left_right	Today, 17:02:26	10s
left_right.285c9cui	left_right	Today, 17:01:14	10s

Record new data

Device ?  
phone\_kl72ebm0

Label  
left\_right

Sample length (ms.)  
10000

Sensor  
Accelerometer

Frequency  
62.5Hz

Start sampling

RAW DATA  
left\_right.285cdp4k

accX accY accZ

**EDGE IMPULSE**

DATA ACQUISITION (IESTI01 - GESTURE CLASSIFICATION)

Training data Test data

Did you know? You can capture data from any device or development board, or upload your existing datasets - Show options

DATA COLLECTED  
5m 24s

LABELS  
4

Collected data

SAMPLE NAME LABEL ADDED LENGTH

- idle.285d4180 idle Today, 17:15:47 10s
- idle.285d3fb6 idle Today, 17:15:29 10s
- idle.285d2sbr idle Today, 17:15:09 10s
- idle.285d28r0 idle Today, 17:14:49 10s
- idle.285d1mbb idle Today, 17:14:30 10s
- idle.285d14km idle Today, 17:14:12 10s
- idle.285d08ko idle Today, 17:13:43 7s
- idle.285cv3pi idle Today, 17:13:06 6s
- idle.285ctsf7 idle Today, 17:12:25 10s
- idle.285ctcve idle Today, 17:12:10 10s
- circle.285csk7d circle Today, 17:11:44 10s
- circle.285cqsc4 circle Today, 17:10:47 10s

When finished, go to "Create Impulse"

Record new data

Device ⓘ  
No devices connected

Label  
idle

Sensor

Frequency


Sample length (ms.)  
10000

Start sampling

RAW DATA  
idle.285d4180

accX accY accZ

Refresh App at mobile if necessary



## EDGE IMPULSE

- Dashboard
- Devices
- Data acquisition
- Impulse design
- Create impulse**
- Retrain model
- Live classification
- Model testing
- Versioning
- Deployment

### GETTING STARTED

- Documentation
- Forums

### CREATE IMPULSE (IESTI01 - GESTURE CLASSIFICATION)



MJRoBot (Marcelo Rovai)

An impulse takes raw data, uses signal processing to extract features, and then uses a learning block to classify new data.

#### Time series data



##### Axes

accX, accY, accZ

##### Window size

2000 ms.

##### Window increase

80 ms.

##### Zero-pad data

■

Add a processing block

Add a learning block

#### Output features



Save Impulse

**CREATE IMPULSE (IESTI01 - GESTURE CLASSIFICATION)**

An impulse takes raw data, uses signal processing to extract features, and then classifies them.

**Time series data**

Axes: accX, accY, accZ

Window size: 2000 ms.

Window increase: 80 ms.

Zero-pad data:

**Add a processing block**

**Spectral Analysis** Great for analyzing repetitive motion, such as data from accelerometers. Extracts the frequency and power characteristics of a signal over time. Author: EdgeImpulse Inc. Recommended. Add

**Flatten** Flatten an axis into a single value, useful for slow-moving averages like temperature data, in combination with other blocks. Author: EdgeImpulse Inc. Add

**Image** Preprocess and normalize image data, and optionally reduce the color depth. Author: EdgeImpulse Inc. Add

**Audio (MFCC)** Extracts features from audio signals using Mel Frequency Cepstral Coefficients, great for human voice. Author: EdgeImpulse Inc. Add

**Audio (MFE) EXPERIMENTAL** Extracts a spectrogram from audio signals using Mel-filterbank energy features, great for non-voice audio. Author: EdgeImpulse Inc. Add

**Spectrogram EXPERIMENTAL** Extracts a spectrogram from audio or sensor data, great for non-voice audio or data with continuous frequencies. Author: EdgeImpulse Inc. Add

**Audio (Syntiant) EXPERIMENTAL** Syntiant only. Compute log Mel-filterbank energy features from an audio signal. Author: EdgeImpulse Inc. Add

**Raw Data** Use data without pre-processing. Useful if you want to use deep learning to learn features. Author: EdgeImpulse Inc. Add

**Add custom block** Cancel

**Output features**

Save Impulse

studio.edgeimpulse.com

Create impulse - IESTI01 - Gesture Classification - Edge Impulse

EDGE IMPULSE

CREATE IMPULSE (IESTI01 - GESTURE CLASSIFICATION)

An impulse takes raw data, uses signal processing to extract features, and then uses a learning block to classify new data.

Time series data

Axes: accX, accY, accZ

Window size: 2000 ms.

Window increase: 80 ms.

Zero-pad data

Spectral Analysis

Name: Spectral features

Input axes: accX, accY, accZ

Add a learning block

Output features

Save Impulse

Dashboard

Devices

Data acquisition

Impulse design

Create impulse

Retrain model

Live classification

Model testing

Versioning

Deployment

GETTING STARTED

Documentation

Forums

© 2020 EdgeImpulse Inc. All rights reserved

The screenshot shows the Edge Impulse Studio interface for creating a gesture classification impulse. The main workspace is divided into three main sections: Time series data, Spectral Analysis, and Output features. The Time series data section is set up to process three axes (accX, accY, accZ) over a window size of 2000 ms and a window increase of 80 ms, with zero-padding enabled. The Spectral Analysis section contains a single block named "Spectral features" that processes the same three axes. The Output features section is currently empty, indicated by a green box with a checkmark. A "Save Impulse" button is located in the bottom right corner of the workspace. The left sidebar provides navigation links for dashboard, devices, data acquisition, impulse design, and project management (create, retrain, live classification, model testing, versioning, deployment). It also includes links for getting started, documentation, and forums. The bottom of the screen displays the copyright information: © 2020 EdgeImpulse Inc. All rights reserved.

studio.edgeimpulse.com

Create impulse - IESTI01 - Gesture Classification - Edge Impulse

EDGE IMPULSE

CREATE IMPULSE (IESTI01 - GESTURE CLASSIFICATION)

An impulse takes raw data, uses signal processing to extract features, and then uses a learning block to classify new data.

Time series data

Axes  
accX, accY, accZ

Window size  
2000 ms.

Window increase  
80 ms.

Zero-pad data

Spectral Analysis

Name

Add a learning block

Output features

Save Impulse

Dashboard

Devices

Data acquisition

Impulse design

Create impulse

Retrain model

Live classification

Model testing

Versioning

Deployment

GETTING STARTED

Documentation

Forums

Edge Impulse Inc. All rights reserved

**Add a learning block**

Some learning blocks have been hidden based on the data in your project.

DESCRIPTION	AUTHOR	RECOMMENDED
Neural Network (Keras) Learns patterns from data, and can apply these to new data. Great for categorizing movement or recognizing audio.	Edgimpulse Inc. ★	Add
K-means Anomaly Detection Find outliers in new data. Good for recognizing unknown states, and to complement neural networks.	Edgimpulse Inc. ★	Add
Regression (Keras) Learns patterns from data, and can apply these to new data. Great for predicting numeric continuous values.	Edgimpulse Inc.	Add

Cancel

© 2020 EdgeImpulse Inc. All rights reserved

MJRoBot (Marcelo Rovai)

studio.edgeimpulse.com

Create impulse - IESTI01 - Gesture Classification - Edge Impulse

EDGE IMPULSE

CREATE IMPULSE (IESTI01 - GESTURE CLASSIFICATION)

An impulse takes raw data, uses signal processing to extract features, and then uses a learning block to classify new data.

Dashboard

Devices

Data acquisition

Impulse design

Create impulse

Retrain model

Live classification

Model testing

Versioning

Deployment

GETTING STARTED

Documentation

Forums

Time series data

Axes: accX, accY, accZ

Window size: 2000 ms.

Window increase: 80 ms.

Zero-pad data

Spectral Analysis

Name: Spectral features

Input axes: accX, accY, accZ

Neural Network (Keras)

Name: NN Classifier

Input features: Spectral features

Output features: 4 (circle, idle, left\_right, up\_down)

Output features

4 (circle, idle, left\_right, up\_down)

Save Impulse

Add a processing block

Add a learning block

© 2020 EdgeImpulse Inc. All rights reserved

EDGE IMPULSE

CREATE IMPULSE (IESTI01 - GESTURE CLASSIFICATION)

Successfully stored impulse. Configure the signal processing and learning blocks in the navigation bar.

Dashboard

Devices

Data acquisition

Impulse design

Create impulse

Spectral features

NN Classifier

Retrain model

Live classification

Model testing

Versioning

Deployment

GETTING STARTED

Documentation

Forums

studio.edgeimpulse.com

Create impulse - IESTI01 - Gesture Classification - Edge Impulse

MJRoBot (Marcelo Rovai)

Time series data

Axes: accX, accY, accZ

Window size: 2000 ms.

Window increase: 80 ms.

Zero-pad data

Spectral Analysis

Name: Spectral features

Input axes: accX, accY, accZ

Neural Network (Keras)

Name: NN Classifier

Input features: Spectral features

Output features: 4 (circle, idle, left\_right, up\_down)

Output features

4 (circle, idle, left\_right, up\_down)

Save Impulse

© 2020 EdgeImpulse Inc. All rights reserved

When Impulse is saved, go to “Spectral features”

studio.edgeimpulse.com

Spectral features - IESTI01 - Gesture Classification - Edge Impulse

MjRoBot (Marcelo Rovai)

**EDGE IMPULSE**

**SPECTRAL FEATURES (IESTI01 - GESTURE CLASSIFICATION)**

**Parameters** **Generate features** **2**

**Raw data**

left\_right.285cd7mh (left\_right)

accX accY accZ

Raw features

-8.7611, -2.9703, -8.5353, -11.3612, -3.4283, -8.0337, -12.3569, -3.5662, -7.5739, -13.2262, -3.2118, -6.1057, -13.3079, -4.7206, -4.7226, -14.6...

Parameters

Scaling

Scale axes

Filter

Type

Cut-off frequency

Order

Spectral power

FFT length

No. of peaks

Peaks threshold

Power edges

**DSP result**

After filter

Frequency domain

Spectral power

Processed features

Save parameters **1**

2



## SPECTRAL FEATURES (IESTI01 - GESTURE CLASSIFICATION)

Parameters Generate features

## Training set

Data in training set	5m 24s
Classes	4 (circle, idle, left_right, up_down)
Window length	2000 ms.
Window increase	80 ms.
Training windows	3,200

Generate features

## Feature explorer

No features generated yet.



© 2020 EdgeImpulse Inc. All rights reserved

Documentation

Forums

Spectral features - IESTI01 - Gesture Classification - Edge Impulse

**EDGE IMPULSE**

**SPECTRAL FEATURES (IESTI01 - GESTURE CLASSIFICATION)**

Parameters [Generate features](#)

**Training set**

- Data in training set: 5m 24s
- Classes: 4 (circle, idle, left\_right, up\_down)
- Window length: 2000 ms.
- Window increase: 80 ms.
- Training windows: 3,200

[Generate features](#)

**Feature generation output**

Scheduling job in cluster...  
Job started  
Creating windows from 35 files...  
[ 1/35] Creating windows from files...  
[35/35] Creating windows from files...  
Created 3200 windows: circle: 773, idle: 886, left\_right: 776, up\_down: 765  
  
Creating features  
[ 1/3200] Creating features...  
[ 920/3200] Creating features...  
[1840/3200] Creating features...  
[2760/3200] Creating features...  
[3200/3200] Creating features...  
Created features  
  
Job completed

[Cancel](#)

**Feature explorer (3,200 samples)**

X Axis: accX RMS, Y Axis: accY RMS, Z Axis: accZ RMS

Legend: circle (blue), idle (orange), left\_right (green), up\_down (red)

**left\_right.285cbio4**  
Window: 160 - 2160 ms.  
Label: left\_right  
[View sample](#) [View features](#)

**On-device performance** ②

PROCESSING TIME: 7 ms.

PEAK RAM USAGE: 5 KB

studio.edgeimpulse.com

NN Classifier - IESTI01 - Gesture Classification - Edge Impulse

MjRoBot (Marcelo Rovai)

### EDGE IMPULSE

NN CLASSIFIER (IESTI01 - GESTURE CLASSIFICATION)  
#1 Click to set a description for this version

**Neural Network settings**

**Training settings**

- Number of training cycles ②: 30
- Learning rate ②: 0.0005
- Minimum confidence rating ②: 0.60

**Neural network architecture**

- Input layer (33 features)
- Dense layer (20 neurons)
- Dense layer (10 neurons)
- Add an extra layer
- Output layer (4 features)

**Training output**

EPOCHS  
Lr

```
graph TD; Input((input)) --> InputLayer[InputLayer]; InputLayer --> Dense1[Dense<br/>kernel 33x20<br/>bias 20]; Dense1 --> ReLU1[ReLU]; ReLU1 --> Dense2[Dense<br/>kernel 20x10<br/>bias 10]; Dense2 --> ReLU2[ReLU]; ReLU2 --> Dense3[Dense<br/>kernel 10x4<br/>bias 4]; Dense3 --> Softmax[Softmax]; Softmax --> yPred((y_pred));
```

Start training

© 2020 EdgeImpulse Inc. All rights reserved

EDGE IMPULSE

NN CLASSIFIER (IESTI01 - GESTURE CLASSIFICATION)  
#1 ▾ Click to set a description for this version

Neural Network settings

Training settings

Number of training cycles ② 30

Learning rate ② 0.0005

Minimum confidence rating ② 0.60

Neural network architecture

Input layer (33 features)

Dense layer (20 neurons)

Dense layer (10 neurons)

Add an extra layer

Output layer (4 features)

Start training

Training output

MJRoBot (Marcelo Rovai)

?

Number of neurons

Enter the new number of neurons for this layer

20

Cancel OK

You can change the number  
of Neurons per Layer  
Or add new layers

NN CLASSIFIER (IESTI01 - GESTURE CLASSIFICATION)  
#1 ▾ Click to set a description for this version

- Dashboard
- Devices
- Data acquisition
- Impulse design
  - Create impulse
  - Spectral features
- NN Classifier
- Retrain model
- Live classification
- Model testing
- Versioning
- Deployment

## GETTING STARTED

- Documentation
- Forums

## Neural Network settings


## Training settings

Number of training cycles ⓘ

Learning rate ⓘ

Minimum confidence rating ⓘ

## Neural network architecture



Start training

© 2020 EdgeImpulse Inc. All rights reserved

Did you know? You have access to the full set of Keras layers through the Expert view (click on ⚙ to switch).

LAYER TYPE

**Dense**  
Fully connected layer, the simplest form of a neural network layer. Use this for processed data, such as the output of a spectral analysis DSP block. Add

**1D Convolution / pooling**  
Learn features that take spatial information into account along a single dimension. Use this for raw data, or for DSP blocks that output spatial data, such as the MFCC block. Add


**2D Convolution / pooling**  
Learn features that take spatial information into account along two dimensions. Use this for raw data, or for DSP blocks that output spatial data, such as the MFCC block. Add

**Reshape**  
Turn one-dimensional data from a DSP block into multi-dimensional data. Use this as an input to a convolutional layer. Use this for deep learning on raw data, or to process MFCC output. Add

**Flatten**  
Flatten multi-dimensional data into a single dimension. You need to flatten data from a convolutional layer before returning. Add

**Dropout**  
Reduce the risk of a model overfitting your dataset by randomly cutting a fraction of network connections during training. Can be helpful if your model's training performance is better than its validation performance. Add

Cancel



EDGE IMPULSE

- Dashboard
- Devices
- Data acquisition
- Impulse design
- Create impulse
- Spectral features
- NN Classifier
- Retrain model
- Live classification
- Model testing
- Versioning
- Deployment

## GETTING STARTED

- Documentation
- Forums

## NN CLASSIFIER (IESTI01 - GESTURE CLASSIFICATION)

#1 ▾ Click to set a description for this version

## Neural Network settings

## Training settings

Number of training cycles ②

30

Learning rate ②

0.0005

Minimum confidence rating ②

0.60

## Neural network architecture

## Input layer (33 features)

## Dense layer (20 neurons)

## Dense layer (10 neurons)

Add an extra layer

## Output layer (4 features)

Start training

## Training output

```
80/80 - ls - loss: 0.0105 - accuracy: 0.9977 - val_loss: 0.0069 - val_accuracy: 0.9984
Epoch 24/30
80/80 - ls - loss: 0.0098 - accuracy: 0.9980 - val_loss: 0.0063 - val_accuracy: 0.9984
Epoch 25/30
80/80 - ls - loss: 0.0091 - accuracy: 0.9988 - val_loss: 0.0059 - val_accuracy: 1.0000
Epoch 26/30
80/80 - ls - loss: 0.0086 - accuracy: 0.9988 - val_loss: 0.0054 - val_accuracy: 1.0000
Epoch 27/30
80/80 - ls - loss: 0.0080 - accuracy: 0.9988 - val_loss: 0.0050 - val_accuracy: 1.0000
Epoch 28/30
80/80 - ls - loss: 0.0076 - accuracy: 0.9992 - val_loss: 0.0047 - val_accuracy: 1.0000
Epoch 29/30
80/80 - ls - loss: 0.0071 - accuracy: 0.9992 - val_loss: 0.0043 - val_accuracy: 1.0000
Epoch 30/30
80/80 - ls - loss: 0.0067 - accuracy: 0.9992 - val_loss: 0.0040 - val_accuracy: 1.0000
Finished training
```

## Model

Model version: ② Quantized (int8) ▾

## Last training performance (validation set)

ACCURACY  
100.0%

LOSS  
0.00

## Confusion matrix (validation set)

	CIRCLE	IDLE	LEFT_RIGHT	UP_DOWN
CIRCLE	100%	0%	0%	0%
IDLE	0%	100%	0%	0%
LEFT_RIGHT	0%	0%	100%	0%
UP_DOWN	0%	0%	0%	100%
F1 SCORE	1.00	1.00	1.00	1.00


## Feature explorer (full training set) ②

accX RMS

accY RMS

accZ RMS

- circle - correct
- idle - correct
- left\_right - correct
- up\_down - correct



Live classification - IESTI01 - Gesture Classification - Edge Impulse

LIVE CLASSIFICATION (IESTI01 - GESTURE CLASSIFICATION)

Did you know? Capture data from any device or development board into the testing category to live classify data - Show options

No devices connected

10000

Start sampling

testing.285ganlg (testing)

Load sample

EDGE IMPULSE

Dashboard

Devices

Data acquisition

Impulse design

Create impulse

Spectral features

NN Classifier

Retrain model

Live classification

Model testing

Versioning

Deployment

GETTING STARTED

Documentation

Forums

Live classification - IESTI01 - Gesture Classification - Edge Impulse

### LIVE CLASSIFICATION (IESTI01 - GESTURE CLASSIFICATION)

**Did you know?** Capture data from any device or development board into the *testing* category to live classify data - Show options

#### Classify new data

Device: phone\_kl72ebm0  
Sensor: Accelerometer  
Sample length (ms.): 10000  
Frequency: 62.5Hz

Sampling... (5s left)

#### Classify existing test sample

left-right.285fs6p7 (left-right)  
Load sample

#### Classification result

##### Summary

CATEGORY	COUNT
circle	97
idle	0
left_right	0
up_down	0
uncertain	0

##### Detailed result

TIMESTAMP	CIRCLE	IDLE	LEFT_RIGHT	UP_DOWN
1	0	0	0	0
2	0	0	0	0
3	0	0	0	0
4	0	0	0	0
5	0	0	0	0
6	0	0	0	0
7	0	0	0	0
8	0	0	0	0
9	0	0	0	0
10	0	0	0	0

Show only unknowns

#### RAW DATA

testing.285g61cg

Raw features

```
-2.1183, -9.0592, -3.1488, -2.2401, -9.0986, -3.1581, -2.2494, -9.0845, -3.1066, -2.3941, -8.9558, -3.0458, -2.3116, -9.0658, -2.8653, -2.2467, -
```

#### Spectral features (3,297 samples)

X Axis: accX RMS  
Y Axis: accY RMS  
Z Axis: accZ RMS

studio.edgeimpulse.com

Live classification - IESTI01 - Gesture Classification - Edge Impulse

## Classification result

**Summary**

Name	testing.285g61cg
Expected outcome	testing
CATEGORY	COUNT
circle	97
idle	0
left_right	0
up_down	0
uncertain	0

**Detailed result**

TIMESTAMP	CIRCLE	IDLE	LEFT_RIGHT	UP_DOWN
0	0.98	0	0.02	0
80	1.00	0	0	0
160	1.00	0	0	0
240	1.00	0	0	0
320	1.00	0	0	0
400	1.00	0	0	0
480	1.00	0	0	0
560	1.00	0	0	0
640	1.00	0	0	0
720	1.00	0	0	0
...	...	...	...	...

Show only unknowns

**RAW DATA**  
testing.285g61cg

Raw features

```
-2.1183, -9.0592, -3.1488, -2.2401, -9.0986, -3.1581, -2.2494, -9.0845, -3.1066, -2.3941, -8.9558, -3.0450, -2.3116, -9.0658, -2.8653, -2.2467, ...
```

**Spectral features (3,297 samples)**

X Axis: accX RMS, Y Axis: accY RMS, Z Axis: accZ RMS

Legend:

- circle (blue)
- classified (orange)
- idle (green)
- left\_right (red)
- up\_down (purple)
- classification 0 (cyan)

**Processed features**

```
7.8824, 1.4881, 7.5658, 2.4802, 1.4722, 4.9603, 0.1052, 0.2894, 5.8086, 3.0277, 0.0688, 4.4396, 1.4881, 3.9708, 2.4802, 0.8712, 3.4722, 0.5139, ...
```

## GETTING STARTED

## MODEL TESTING (IESTI01 - GESTURE CLASSIFICATION)

This lists all test data. You can manage this data through [Data acquisition](#).

## Test data

Set the 'expected outcome' for each sample to the desired outcome to automatically score the impulse.

SAMPLE NAME	EXPECTED OUTCOME	LENGTH	ACCURACY	RESULT	⋮
testing.285gma46	up_down	10s	100%	97 up_down	⋮
testing.285ganlg	idle	4s	100%	24 idle	⋮
testing.285g61cg	circle	10s	100%	97 circle	⋮
testing.285g354a	left_right	10s	100%	97 left_right	⋮
left-right.285fs6p7	left_right	10s	100%	96 left_right	⋮

## Validation output

Created features  
Generating features for Spectral features OK

Classifying data for NN Classifier...  
Copying features from DSP block...  
Copying features from DSP block OK  
Classifying data for float32 model...  
Scheduling job in cluster...  
Job started  
Classifying data for NN Classifier OK

Job completed

## Validation results


ACCURACY  
**100.00%** %

	CIRCLE	IDLE	LEFT_RIGHT	UP_DOWN	UNCERTAIN
CIRCLE	<b>100%</b>	0%	0%	0%	0%
IDLE	0%	<b>100%</b>	0%	0%	0%
LEFT_RIGHT	0%	0%	<b>100%</b>	0%	0%
UP_DOWN	0%	0%	0%	<b>100%</b>	0%

## Feature explorer ⓘ

accX RMS accY RMS accZ RMS

- circle - correct
- idle - correct
- left\_right - correct
- up\_down - correct



studio.edgeimpulse.com

NN Classifier - IESTI01 - Gesture Classification - Edge Impulse

MjRoBot (Marcelo Rovai)

### NN CLASSIFIER (IESTI01 - GESTURE CLASSIFICATION)

#1 ▾ Click to set a description for this version

Neural Network settings

Training settings
 

Number of training cycles (30)
 

Switch to Keras (expert) mode

Edit as iPython notebook

 Learning rate (0.0005)
 
 Minimum confidence rating (0.60)

Neural network architecture

Input layer (33 features)

Dense layer (20 neurons)

Dense layer (10 neurons)

Add an extra layer

Output layer (4 features)

Start training

Training output

Model
 

Last training performance (validation set)
 

ACCURACY 100.0%

LOSS 0.00

 Model version: (Quantized (int8))

Confusion matrix (validation set)
 

	CIRCLE	IDLE	LEFT_RIGHT	UP_DOWN
CIRCLE	100%	0%	0%	0%
IDLE	0%	100%	0%	0%
LEFT_RIGHT	0%	0%	100%	0%
UP_DOWN	0%	0%	0%	100%
F1 SCORE	1.00	1.00	1.00	1.00

Feature explorer (full training set)
 

accX RMS
 

▼

 accY RMS
 

▼

 accZ RMS
 

▼

● circle - correct  
 ● idle - correct  
 ● left\_right - correct  
 ● up\_down - correct

On-device performance

INFERENCING TIME  
1 ms.

PEAK RAM USAGE  
1.5K

ROM USAGE  
15.4K

EDGE IMPULSE

NN CLASSIFIER (IESTI01 - GESTURE CLASSIFICATION)

#1 ▾ Click to set a description for this version

Neural Network settings

Training settings

Minimum confidence rating ② 0.60

Neural network architecture

```
1 import tensorflow as tf
2 from tensorflow.keras.models import Sequential
3 from tensorflow.keras.layers import Dense, InputLayer, Dropout, Conv1D, Conv2D, Flatten, Reshape, MaxPooling1D,
   MaxPooling2D, BatchNormalization
4 from tensorflow.keras.optimizers import Adam
5 sys.path.append('./resources/libraries')
6 import ei_tensorflow.training
7
8 # model architecture
9 model = Sequential()
10 model.add(Dense(20, activation='relu',
11                 activity_regularizer=tf.keras.regularizers.l1(0.0001)))
12 model.add(Dense(10, activation='relu',
13                 activity_regularizer=tf.keras.regularizers.l1(0.0001)))
14 model.add(Dense(classes, activation='softmax', name='y_pred'))
15
16 # this controls the learning rate
17 opt = Adam(lr=0.0005, beta_1=0.9, beta_2=0.999)
18 # this controls the batch size, or you can manipulate the tf.data.Dataset objects yourself
19 BATCH_SIZE = 32
20 train_dataset = train_dataset.batch(BATCH_SIZE, drop_remainder=False)
21 validation_dataset = validation_dataset.batch(BATCH_SIZE, drop_remainder=False)
22 callbacks.append(BatchLoggerCallback(BATCH_SIZE, train_sample_count))
23
24 # train the neural network
25 model.compile(loss='categorical_crossentropy', optimizer=opt, metrics=['accuracy'])
26 model.fit(train_dataset, epochs=30, validation_data=validation_dataset, verbose=2, callbacks=callbacks)
```

Start training

Training output

Model

Last training performance (validation set)

ACCURACY 100.0% LOSS 0.00

Confusion matrix (validation set)

	CIRCLE	IDLE	LEFT_RIGHT	UP_DOWN
CIRCLE	100%	0%	0%	0%
IDLE	0%	100%	0%	0%
LEFT_RIGHT	0%	0%	100%	0%
UP_DOWN	0%	0%	0%	100%
F1 SCORE	1.00	1.00	1.00	1.00

Feature explorer (full training set) ②

accX RMS accY RMS accZ RMS

- circle - correct
- idle - correct
- left\_right - correct
- up\_down - correct

On-device performance ②

INFERRING TIME 1 ms. PEAK RAM USAGE 1.5K ROM USAGE 15.4K

MJRoBot (Marcelo Rovai)

# Reading Material

# Main references

- [Harvard School of Engineering and Applied Sciences - CS249r: Tiny Machine Learning](#)
- [Professional Certificate in Tiny Machine Learning \(TinyML\) – edX/Harvard](#)
- [Introduction to Embedded Machine Learning \(Coursera\)](#)
- [Text Book: "TinyML" by Pete Warden, Daniel Situnayake](#)

I want to thank **Shawn Hymel and Edge Impulse**, [Laurence Moroney from Google](#), [Harvard professor Vijay Janapa Reddi](#), Ph.D. student [Brian Plancher](#) and their staff for preparing the excellent material on TinyML that is the basis of this course at UNIFEI.

The IESTI01 course is part of the [TinyML4D](#), an initiative to make TinyML education available to everyone globally.

**Thanks**  
And stay safe!

